VERSION 8 SYSTEM



AR56VB-1

System Configuration
AN/TPQ-36(V)8

SHELTER

ANTENNA TRANSCEIVER GROUP



RECONN VEHICLE

SPARE GENERATOR TRAILER



GENERATOR PALLET

EQUIPMENT TRAILER GROUP



System Configuration
AN/TPQ-46A









VERSION 8 SYSTEM SOFTWARE

LCU SOFTWARE

-- MAJOR OPERATOR/SYSTEM INTERFACE AND CONTROL

-- BEGINS INITIALIZATION PROGRAM

-- WEAPONS LOCATION AND IMPACT PREDICT

-- EMBEDDED TRAINING

-- COMMUNICATIONS SOFTWARE

-- SHELTER AND ATG BIT FUNCTIONS

VERSION 8 SYSTEM SOFTWARE

LCU CONTROL PROCESSING

-- OUTPUT TO DISPLAY AND PRINTER

-- KEYBOARD/TRACKBALL INPUT

-- TCIM INTERFACE

-- PAPER MAP DISPLAY

-- CD ROM INPUT (DTED)

-- LCU HARD DRIVE INTERFACE

-- LOCAL MEMORY

-- RADAR PROCESSOR INTERFACE

-- FITS AND MAINTENANCE AID

Light Control Panel



VERSION 8 SYSTEM



AR56VB-4

VERSION 8 SYSTEM



AR56VB-5

VERSION 8 SYSTEM

AR56VB-6

VERSION 8 SYSTEM



AR56VB-3

VERSION 8 SYSTEM

Control Panel



Map Display

AR56VB-7

VERSION 8 SYSTEM



AR56VB-9

VERSION 8 SYSTEM



AR56VB-8

VERSION 8 SYSTEM



AR56VB-10

VERSION 8 SYSTEM



AR56VB-11

VERSION 8 SYSTEM



AR56VB-12

Vehicle Cab Control Console (VCCC)



VERSION 8 SYSTEM



AR56VB-13

Miscellaneous Components





VERSION 8 SYSTEM





AR56VB-16